



Gear in motion

## ORCA Bags 2014 Compatibility Chart

### Shouldered Camera Bags

ORCA Bag Model	Sony	Canon	Panasonic	JVC	Black Magic
<b>OR-4</b>	HXR-NX30, HMC-50, HXR-NX70, NEX-VG30, NEX-VG900	XA-10, XA-20, XA-25			
<b>OR-6</b>	PXW-Z100, FDR-AX-1 4K, PMW-F5, PMW-F55, PXW-X180	C-100, C-300, AF-100, XF-300, XF-200HD, XF-205	AG-AC90, AG-HMC-150, AG-AC-130A, AG-AC-160A, AG-AF100A	GY-HM 150U, GY-HM 600, GY-HM 650	2K, 4K
<b>OR-8</b>	HXR-NX3, NEX- EA50, HXR-NX5, PMW-100, PMW-150, PMW-200, HVR-Z5, HXR-NX5, DCR-VX2200, PXW-Z100, FDR-AX1, HDR-AX2000, HDR-FX1000, PXW-X180, EX-1R	XF-100, XF-300	AG-AC90, AG-HMC150, AG-AC130A, AG-AC160A, AG-HPX-250, AG-AF100, HPX-255, AJ-PX270	GY-HM 150, GY-HM 600, GY- HM 650	
<b>OR-12</b>	HXR-MC2000, NEX-FS700, NEX- EA50 , PMW-300,EX-3, NEX-FS-100, HXR-MC-1500, PMW-F5, PMW-F55		AG-AC8, AG-HPX-250, AG-HMC-80, AJ- PX 270, HDC-MDH-1	GY- HM70 , GY- HM-710, HM-750 , HM-850, HM-890	2K, 4K



Gear in motion

## ORCA Bags 2014 Compatibility Chart

### Backpacks

ORCA Bag Model	Sony	Canon	Panasonic	JVC	Black Magic
<b>OR-20</b>	HXR-NX30, HMC-50, HXR-NX70, NEX-VG30, NEX-VG900	TBA	TBA	TBA	2K, 4K
<b>OR-22</b>	PXW-Z100, FDR-AX-1 4K, PMW-100, PMW-150, PMW-200, PXW-X180	TBA	AG-AC90, AG-HMC-150, AG-AC-130A, AG-AC-160A, AG-AF100A	GY-HM 150U, GY-HM 600, GY-HM 650	
<b>OR-24</b>	EX-3, PMW-300	TBA	HPX-250, AG-AF100, HPX-255, AJ-PX270	TBA	



BAGS

# ORCA Bags 2014 Compatibility Chart

Gear in motion

## Sound Bags

Mixer Model	OR-30	OR-32	OR-34
Zaxcom	MAX	NOMAD-4, NOMAD-6, NOMAD-8, NOMAD-10, NOMAD-12	NOMAD-4, NOMAD-6, NOMAD-8, NOMAD-10, NOMAD-12, DIVA
Sound Devices	SD-633, SD-MIXPRE, SD-302, SD-788T	SD-552 , SD- 664 , SD-664 + CL-6, SD-788T, SD-788T + CL-8	SD-552, SD-664, SD-664 + CL-6, SD-788T+ CL-8, SD-664 + LECTROSONIC VR-FIELD with up to 6 receivers
Shure	FP-33		
Azden	FMX-42, FMX-22, FMX-32A	FMX-42 , FMX- 32A	
Rolls	MX-124	MX-410, MX-422	MX-410, MX-422
Kamesan	KS-T2000	KS-6001, KS-342	KS-6001, KS-342
PSC	DVPROMIX 3	DVPROMIX 3	DVPROMIX 3
Audio Development	MX-124	MX-410, MX-422	MX-410, MX-422
Sony		DMX-PO1	
Fostex		FM-3, FM-4	



Gear in motion

## ORCA Bags 2014 Compatibility Chart

### LCD Hoods

ORCA LCD Hood Model	Sony	Canon	Panasonic
<b>OR-50</b>	HXR-NX3, NEX-FS700, PMW-100/200, NX-5, PDW-700, HVR-Z5/Z7		AG-3DA1
<b>OR-52</b>	EX1R, DSR-450, PMW-100, HVR-V1	C-100	AG-HPX2700, DVX-100, HVC-154, HVX-204, F-3
<b>OR-56</b>	DSR-PD100	C-300	130/160A, AG-AP-101