

Orca Bags 2014 Compatibility Chart

Category	Orca Bag model	Sony	Canon	Arri Alexa	Panasonic	JVC	Blackmagic
SHOULDER BAGS	OR-4	HXR-NX30, HMC-50, HXR-NX70, NEX-VG30, NEX-VG90, PXW-X70, PXW-X70	XA-10, XA-20, XA-25, EOS 1DC, XF-105, XC-10			GY-HM-170, GY-HM-200	
	OR-6	PXW-Z100, FDR-AX-1 4K, PMW-F5, PMW-F55, PXW-X180, PXW-X70, FS-7 w/o Lens, FS-7K w/o Lens,	XA-20, XA-25, C-100, EOS 1DC, C-300, AF-100, XF-105, XF-300, XF-200HD, XF-205	New Mini Alexa	AG-AC90, AG-HMC-150, AG-AC-130A, AG-AC-160A, AG-AF100A	GY-HM150U, GY-HM600, GY-HM650, GY-LS-330LS, GY-LS300	2K, 4K
	OR-8	HXR-NX3, NEX-EA50, HXR-NX5, PMW-100, PMW-150, PMW-200, HVR-Z5, HXR-NX5, DCR-VX2200, PXW-Z100, FDR-AX1, HDR-AX2000, HDR-FX1000, PXW-180, EX-1R, PXW-160, FS-7 with Lens, FS-7K with Lens,	XF-100, XF-205, XF-300, XF-305, XF105HD		AG-AC90, AG-HMC150, AG-AC130A, AG-AC160A, AG-HPX-250, AG-AF100, HPX-255, AJ-PX-270, HC-X10004K	GY-HM150, GY-HM600, GY-HM-650, GY-LS-330LS, GY-HM-170, GY-HM-200, GY-LS3004K, GY-HM2004K	
	OR-10					GY-LS300	
	OR-12	HXR-MC2000, NEX-FS700, NEX- EA50, PMW-300, EX-3, NEX-FS-100, PXW-Z100, HXR-MC-1500, HXR-MC-2500, PMW-F5, PMW-F55, FS-7 with Lens, FS-7K whit Lens,	XF-305		AG-AC8, AG-HPX-250, AG-HMC-80, AG-AC-8EJ, AG-AC8PJ HD, AJ-PX-270, HDC-MDH-1	GY- HM70, GY- HM-710, HM-750, HM-850, HM-890	2K, 4K
BACKPACKS	OR-20	HXR-NX30, HMC-50, HXR-NX70, NEX-VG30, NEX-VG90, PXW-X70,	EOS 1DC, XC-10		TBA	TBA	2K, 4K
	OR-22	PXW-Z100, FDR-AX-1 4K, PMW-100, PMW-150, PMW-200, PXW-180, PXW-160,	XA-20, XA-25, XF-105, XF-205,		AG-AC90, AG-HMC-150, AG-AC-130A, AG-AC-160A, AG-AF100A, AJ- PX 270 ,	GY-HM150U, GY-HM600, GY-HM650, GY-LS300	
	OR-24	EX-3, PMW-300, PXW-160, PXW-180, FS-7 with Lens, FS-7K whit Lens,	XF-305		HPX-250, AG-AF100, HPX-255, AJ-PX270	GY-LS300	
Category	Mixer Model	OR-30	OR-32	OR-34	OR-41		
SOUND BAGS	Zaxcom	MAX	NOMAD-4, NOMAD-6, NOMAD-8, NOMAD-10, NOMAD-12	NOMAD-4, NOMAD-6, NOMAD-8, NOMAD-10, NOMAD-12, DIVA	Zaxcom Nomad, Zaxcom Nomad + FP-8.		
	Sound Devices	SD-633, SD-MIXPRE, SD-302, SD-788T	SD-552, SD- 664, SD-664 + CL-6, SD-788T, SD-788T + CL-8	SD-552, SD-664, SD-664 + CL-6, SD-788T+ CL-8, SD-664 + LECTROSONIC VR-FIELD with up to 6 receivers	SD-552, SD-788T, SD-788T + CL-8.		
	Shure	FP-33					
	Azden	FMX-42, FMX-22, FMX-32A	FMX-42, FMX- 32A				
	Rolls	MX-124	MX-410, MX-422	MX-410, MX-422			
	Kamesan	KS-T2000	KS-6001, KS-342	KS-6001, KS-342			
	Zoom F8	Multi Track Field Recorder					
	PSC	DVPROMIX 3	DV- PROMIX 3	DV-PROMIX 3			
	Audio Development	AD-071					
Sony		DMX-PO1	DMX-PO1				
Fostex		FM-3, FM-4					
Category	Model	Sony	Canon	Panasonic			
HOODS	OR-50	HXR-NX3, NEX-FS700, PMW-100/200, NX-5, PDW-700, HVR-Z5/Z7	XF-105, XF-205,	AG-3DA1, AJ- PX 270 ,			
	OR-52	EX1R, DSR-450, PMW-100, HVR-V1,	XA-20, XA-25, C-100	AG-HPX2700, DVX-100, HVC-154, HVX-204, F-3			
	OR-56	DSR-PD100	C-300, XF-305,	130/160A, AG-AP-101			
Category	Model	Sony	Panasonic	JVC	Canon		
RAINCOVER	OR-100	PXW-X70					
	OR-102	HXR-NX3, HXR-NX5, PMW-100, PMW-150, PMW-200, HVR-Z5, HXR-NX5, PXW-Z100, , PXW-160, PXW-180,	AG-AC90, AG-HMC-150, AG-AC-130A, AG-AC-160A, HPX-250, HPX-255, AJ-PX270	GY-HM150, GY-HM 600, GY- HM -650	XA-20, XA-25, AF-100, XF-105, XF-300, XF-200HD, XF-205		
	OR-104	PXW-FS7					