



Gear in motion

Orca Bags 2016/17 Compatibility Chart

Category	Orca Bag model	Sony	Canon	ARRI Alexa	Panasonic	JVC	Blackmagic	AJA	RED
SHOULDER BAGS	OR-4	HXR-NX30, HMC-50, HXR-NX70, NEX-VG30, NEX-VG90, PXW-X70/4K, PXW-FS5 w/o Lens, A7S mark II, All DSLR and Cyber shot camera	XA-10, XA-20, XA-25, EOS 1DC, XC-10, XC-10 XF-105, XC-10, ME20F-SH EOS 1DC	New Mini Alexa	GH4, AG-AC90 all Panasonic DSLR camera	GY-HM-170, GY-HM-200	2K, 4K, MINI URSA		
	OR-6	PXW-Z100, FDR-AX-1 4K, PMW-FS5/FSSK, PXW-X180, PXW-X70/4K, FS-7 w/o Lens, NX100, PXW-Z150.	XA-20, XA-25, C-100 M II, EOS 1DC, C-300, AF-100, XF-105, XF-300, XF-200HD, XF-205, ME20F-SH	New Mini Alexa	AG-AC90, AG-HMC-150, AG-AC-130A, AG-AC-160A, AG-AF100A, AG-DVX200, UX-90, LUX-180	GY-HM150/170, GY-HM200/600, GY-HM550, GY-LS-330LS, GY-LS300	2K, 4K, MINI URSA		RAVEN WAPEN
	OR-7	PXW-Z100, FDR-AX-1 4K, PMW-FS5/FSSK, PXW-X180, PXW-X70/4K, FS-7 w/o Lens, NX100, PXW-Z150.	XA-20, XA-25, C-100 II	New Mini Alexa	AG-AC90, AG-HMC-150, AG-AC-130A, AG-AC-160A, AG-AF100A, AG-DVX200, UX-90, LUX-180	GY-HM150/170, GY-HM200/600, GY-HM550, GY-LS-330LS, GY-LS300	2K, 4K, MINI URSA		
	OR-8	HXR-NX3, NEX-EA50, HXR-NXSR, PMW-100, PMW-150, PMW-200, HVR-25, HXR-NX5, DCR-VX2200, PXW-Z100, FDR-AX1, HDR-AX2000, HDR-FX1000, PXW-X180/200, EX-1R, PXW-X160, FS-7, HXR-NX100, PXW-Z150.	XA-20, XA-25, C-100 II, EOS 1DC, C-300, AF-100, XF-105, XF-300, XF-200HD, XF-205, ME20F-SH	New Mini Alexa	AG-AC90, AG-HMC-150, AG-AC-130A, AG-AC-160A, AG-AF100A, AG-DVX200, UX-90, LUX-180	GY-HM150, GY-HM600, GY-HM-650, GY-LS-330LS, GY-HM-170, GY-HM-200, GY-LS3004K, GY-HM2004K			
	OR-9	HXR-NX3, NEX-EA50, HXR-NXSR, PMW-100, PMW-150, PMW-200, HVR-25, HXR-NX5, DCR-VX2200, PXW-Z100, FDR-AX1, HDR-AX2000, HDR-FX1000, PXW-X180, EX-1R, PXW-X160, FS-7 w/o Lens, FS-7K with Lens, PXW-X280, HXR-NX100, PXW-FSSK, PXW-Z150	XA-20, XA-25, C-100, EOS 1DC, C-300, AF-100, XF-105, XF-300, XF-200HD, XF-205, ME20F-SH	ALEXA.	AG-AC90, AG-HMC150, AG-AC130A, AG-AC160A, AG-HPX-250, AG-AF100, HPX-255, AJ-PX-270, HC-X10004K, AG-DVX200, HC-X1000, UX-90, LUX-180.	GY-HM150/170, GY-HM600, GY-HM-650, GY-LS-330LS, GY-HM200, GY-LS3004K, GY-HM2004K			RAVEN WAPEN
	OR-10	HXR-NX3, NEX-EA50, HXR-NXSR, PMW-100, PMW-150, PMW-200, HVR-25, HXR-NX5, DCR-VX2200, PXW-Z100, FDR-AX1, HDR-AX2000, HDR-FX1000, PXW-X180, EX-1R, PXW-X160, FS-7 w/o Lens, FS-7K with Lens, PXW-X280, HXR-NX100, PXW-FSSK, PXW-Z150, FDR-AX1	C-300, AF-100, XF-105,	ALEXA.	AG-HMC150, AG-AC130A, AG-AC160A, AG-HPX-250, AG-AF100, HPX-255, AJ-PX-270, HC-DVX200, HC-X1000, UX-90, LUX-180.	GY-HM150, GY-HM600, GY-HM-650, GY-LS-330LS, GY-HM-170, GY-HM-200, GY-LS3004K, GY-HM2004K			RAVEN WAPEN SCARLET
	OR-11	ALL DSLR MIRROR LESS CAMERAS and Cyber shot, HXR-NX3, NEX-EA50, HXR-NXSR, PMW-100, PMW-150, PMW-200, HVR-25, HXR-NX5, DCR-VX2200, PXW-Z100, FDR-AX1, HDR-AX2000, HDR-FX1000, PXW-X180/200, EX-1R, PXW-X160, FS-7, HXR-NX100, PXW-Z150.	XF-300, XF-200HD, XF-205, ME20F-SH	New Mini Alexa	AG-AC90, AG-HMC-150, AG-AC-130A, AG-AC-160A, AG-AF100A, AG-DVX200, UX-90, LUX-180	GY-HM150, GY-HM600, GY-HM-650, GY-LS-330LS, GY-HM-170, GY-HM-200, GY-LS3004K, GY-HM2004K	2K, 4K, MINI URSA		
	OR-12	HXR-MC2000, NEX-FS700, NEX-EA50, PMW-300, EX-3, NEX-FS-100, PXW-Z100, HXR-MC-1500, HXR-MC-2500, PMW-F5, PMW-F55, FS-7 with Lens, FS-7K w/o Lens, PXW-FSSK.	XF-305, XF-205, C-700.		AG-AC8, AG-HPX-250, AG-HM800, AG-AC-8EJ, AG-AC8PJ, HD, AJ-PX-270, HDC-MDH-1, AG-DVX200, UX-90, LUX-180	GY-HM70, GY-HM710, HM-750, HM-850, HM-890	2K, 4K, URSA		RAVEN WAPEN SCARLET
	OR-14	PXW-FS7K, HXR-MC-2500, DCR-SD1000E, HXR-MC1500E, PXW-X320, PMW-400K, PXW-X500, PDWA-680	C-700.	ALEXA, AMIRA	AG-AC8PJ, AG-HMC80, AG-HPX370, AG-HPX3100, AG-HPX3700, AJ-PX380, AJ-PX398, AJ-PX5000G, AJ-PX800, AG-HPX-610, VARICAM, VARICAM LT	GY-HM850/890	URSA 4K	CION 4K/HD	EPIC DRAGON

	OR-20	HXR-NX30, HMC-50, HXR-NX70, NEX-VG30, NEX-VG90, PXW-X70, PXW-FS5, A7S	EOS 1DC, XC-10, ME20F-SH, XC-10, XC-15, C-100 MARK II	New Mini Alexa	GH4	TBA	2K, 4K		
	OR-22	PXW-Z100, FDR-AX-1 4K, PMW-100, PMW-150, PMW-X200, PXW-X180, PXW-160, PXW-FS5K, NXR-NX100, PXW-Z150, NEX5R,	XA-20, XA-25, XF-105, XF-205, XC-10, XC-15, C-100 MARK II, C-300 MARK II	New Mini Alexa	AG-AC90, AG-HMC-150, AG-AC-130A, AG-AC-160A, AG-AF100A, AJ-PX 270, HC-X1000	GY-HM150U, GY-HM600, GY-HM650, GY-LS300	MINI URSA		
Back packs	OR-24	EX-3, PMW-300, PXW-X160, PXW-X180, FS-7 with Lens, FS-7K whit Lens, PMW-X200, PXW-Z150, FS5K	XF-305, XF-205, XC-10, XC-15	New Mini Alexa	HPX-250, AG-AF100, HPX-255, AJ-PX270	GY-LS300	MINI URSA		RAVEN WAPEN SCARLET
	OR-26	PXW-Z100, FDR-AX-1 4K, PMW-100, PMW-150, PMW-200, PXW-160, PXW-160, NXR-NX100, PXW-Z150.	XA-20, XA-25, XF-105, XF-205, XC-10, XC-15, C-100 MARK II.		AG-AC90, AG-HMC-150, AG-AC-130A, AG-AC-160A, AG-AF100A, AJ-PX 270,	GY-HM150U, GY-HM600, GY-HM650, GY-LS300	MINI URSA		
	Mixer Model	OR-30	OR-32	OR-34	OR-41	OR-28	OR-27		
sound bags	Zaxcom	MAX	NOMAD-4, NOMAD-6, NOMAD-8, NOMAD-10, NOMAD-12	NOMAD-4, NOMAD-6, NOMAD-8, NOMAD-10, NOMAD-12, DIVA	Zaxcom Nomad, Zaxcom Nomad + FP-8.	MAX	MAX		
	Sound Devices	SD-633, SD-MIXPRE, SD-302, SD-788T	SD-552, SD-664, SD-664 + CL-6, SD-788T, SD-788T + CL-8, SD-688	SD-552, SD-664, SD-664 + CL-6, SD-788T + CL-8, SD-664 + ELECTROSONIC VR-FIELD with up to 6 receivers, SD-688	SD-552, SD-788T, SD-788T + CL-8.	SD-MIXPRE	SD-MIXPRE		
	Shure	FP-33							
	Azden	FMX-42, FMX-22, FMX-32A	FMX-42, FMX-32A						
	Rolls	MX-124	MX-410, MX-422	MX-410, MX-422					
	Kamesan	KS-T2000	KS-6001, KS-342	KS-6001, KS-342					
	Zoom F8/F4	Multi Track Field Recorder				ZOOM F4/F8	ZOOM F4/F8		
	PSC	DV-PROMIX 3	DV-PROMIX 3	DV-PROMIX 3					
	Audio Development	AD-071							
	Sony		DMX-PO1	DMX-PO1					
	Tascam	DR-701D				DR-701D	DR-701D		
	Fostex		FM-3, FM-4						
Hoods	Model	Sony	Canon	Panasonic	JVC	Blackmagic	AJA		
	OR-50	HXR-NX3, NEX-FS700, PMW-100/200, NX-5, PDW-700, HVR-Z5/Z7, PXW-FS5	XF-105, XF-205, XC-10, XC-15	AG-3DA1, AJ-PX 270,	GY-HM200				
	OR-52	EX1R, DSR-450, PMW-100, HVR-V1,	XA-20, XA-25, C-100	AG-HPX2700, DVX-100, HVC-154, HVX-204, F-3					
	OR-54			DVX-200					
	OR-56	DSR-PD100, PXW-X70, PXW-FS5	C-300, XF-305,	130/160A, AG-AP-101					
RAINCOVER	Model	Sony	Panasonic	JVC	Canon	Blackmagic	AJA	RED	
	OR-100	PXW-X70, NXR-NX100, PXW-FS5			XC-10, XC-15				
	OR-102	HXR-NX3, HXR-NX5, PMW-100, PMW-150, PMW-200, HVR-Z6, HXR-NX5, PXW-Z100, PXW-X160, PXW-X180, PXW-FS5K (fully equipped), PXW-Z150, FDR-AX1	AG-AC90, AG-HMC-150, AG-AC-130A, AG-AC-160A, HPX-250, HPX-255, AJ-PX270, HC-X1000	GY-HM150, GYHM 600, GY-HM-650	XA-20, XA-25, AF-100, XF-105, XF-300, XF-200HD, XF-205	MINI URSA		DRAGON RAVEN WAPEN SCARLET	
	OR-104	PXW-FS7K, PMW-400, PXW-X500	GY-HM70, GY-HM-710, HM-750, HM-850, HM-890		C-700	URSA 4K			
OR-106	PMW-400, PXW-X500	AG-HPX-610, HPX-3100	ALEXA, AMIRA	AG-HPX-610, 2700/3000/3100	URSA 4K	CION 4K/HD	DRAGON		
TRIPODS BAGS	Model	Sachtler	Libec	Miler	Cartoni	Vinten	CamGear	Monfroto	General
	OR-74	ACE L, ACE M, FSB-6(0475), FSB-8(0775, 0750), FSB-4(0375), DV-12 SB SL(1265), FSB-10(1043).	HD650, RS-450, MLX-10M 2 STAGE.	SOLO DV 20, AIR CARBON FIBER 300S, DS-20, SOLODV-10.	FOCUS 6, FOCUS HD, FOCUS 12, FOCUS 22.	XVISION VB-AP2M, VB3-AP2M	MARK 4, MARK 6.	526, 545 GBK.	Tripods up to : 37" , 94 cm.
OR-75	DV 8 with 100mm ball, DV 12, DV 15, Video 15, Video 18, Video 20 fluid Heads.	RT40RB.	2 Stage 100mm + Arrow 55 Fluid Head, Solo DV10, Solo DV20, Solo DV5, 2-Stage 150mm + DS60 head.	A302, gamma, H601, H602, H603, L501, L502, L503, L504, L505.	Vision 10, Vision 3, Vision 5, Vision 6, Vision 8	V15P, V20 P	Nan	Similar size tripods up to : 40.9" , 104 cm.	